

SUPER BIRD & ANIMAL CHASER

The most natural, humane, effective, environmental-friendly way to deter pest birds and wild animals from your property!

Super Bird and Animal Chaser applies powerful frightening techniques for airfield bird control to make the device a very effective bird scaring machine. The combination of predatory bird calls and bird cries plus very strong flashing strobes makes the device to repel pest birds, and unwanted animals effectively and humanely.

Bio-acoustic system broadcasts natural alarm and distress calls with predatory bird calls causing audio alert to those pest birds. The visual impact of strong flashing strobes will deter pest birds and animals from approaching to the protected area. There are two operation modes, **PIR Mode** for small space intensive protection of a fan shaped area of 130°, distance at up to 12 meters (163 square meters) and **AUTO Mode** for large protection area of up to 1 acre (when volume is turned to maximum).

The sounds broadcasted from **Super Bird and Animal Chaser** are digitally recordings of actual predator birds and birds in distress. The bio-acoustic sounds will trick pest birds into believing they are in great and imminent danger. The flashing strobes offer visual impact to cause birds and animals uncomfortable to stay within the protected area. Combining the audio and visual impact, **Super Bird and Animal Chaser** will keep pest birds and unwanted animals away from the protected property, farms, gardens, yards, orchards, vineyards, fish ponds effectively, humanely and economically. The built-in buttons and switches on the front **Control Panel** of the **Super Bird and Animal Chaser** make it possible to set up the device to adapt the various circumstances.

Using no nets, traps, chemicals, you can humanely repel birds and wild animals effectively. Powered by adaptor, the device can be installed at any place with electricity source by hanging it on the post or to a wall.

APPLICATIONS:

Farms, Lawns, Gardens, Yards, Barns, Fish Ponds, Patio, Porch, Factories, Warehouses, Any Property for Security purpose.


BIRDS AFFECTED:

Sparrows, Pigeons, Blackbirds, Crows, Starlings, Other Types of Birds,


WILD ANIMALS AFFECTED:

Monkeys, Squirrels, Rabbits, Boars, Bears, Deer,..., etc.

PRODUCT DIAGRAMS:



CONTROL PANEL:



HOW TO SETUP

1. **AUTO Mode:** When set to **AUTO Mode**, the **TIME INTERVAL** can be adjusted from 5 to 30 minutes by turning the knob clockwise to longer time interval. You may also adjust the **VOLUME** control knob depending on the size of the protected area. The **Super Bird and Animal Chaser** will broadcast sounds and flashing strobes every 5 to 30 minutes automatically. **AUTO Mode** for large protection area of up to 1 acre (when volume is turned to maximum).
2. **PIR Mode:** It takes within 45 seconds to warm up. The **Super Bird and Animal Chaser** will cover a fan-shaped area of 130 degree at a distance of up to 12 meters (163 square meters). When any warm-blooded animal or a bird flies into the coverage area, the device will broadcast the sounds with flashing strobes to scare the intruder away. You may adjust the **VOLUME** knob **slowly** to suitable loudness. **TIME INTERVAL** is of no function in the **PIR Mode**.
3. **FLASH button:** A built-in **FLASH** control button is designed to allow cancelling flashing strobes once required. When depress the **FLASH** button down, the flashing strobe is off.
4. **CDS button:** the **CDS** is a light sensor, when it is at **ON**, the device is operated only in day light time. When the **CDS** is depressed down at **OFF**, the machine is in operation 24 hours, day and night.

HOW TO INSTALL

1. Attach the **Super Bird and Animal Chaser** to a post or wall at 1 to 2.5 meters above ground where the electricity power source is accessible. Plug the adaptor (9VDC, female plug) into the power socket.
2. Set the switch to **AUTO** mode first to adjust volume. Set the **Mode** switch and control buttons / knobs on the **CONTROL PANEL** according to your requirement.
3. Please avoid obstructions within the operation area of the device while in **PIR Mode**.
4. For larger areas such as big yards, farms, orchards, vineyards, fish cultivation area or large fields, it is suggested to use the **AUTO Mode** and adjust **TIME INTERVAL** and **VOLUME** according to the actual environment.
5. Experiment with various locations to find the most effective position to install the **Super Bird and Animal Chaser** is recommended.

IMPORTANT NOTES:

- The device is weatherproof. Do not immerse the device in water or any other liquids.
- Do not modify or temper the device's internal components.
- The PIR detecting system goes on and off as warm-blooded animal movement starts and stops.
- Make sure the lens is clear. Do not handle the lens. Use a damp cloth to wipe any dirt gently. Use no benzene, alcohol or paint thinner.
- For a small area or when used for security purposes, it is suggested to set in the **PIR Mode**.
- Please turn the **VOLUME** knob **slowly** due to powerful sound broadcast.

SPECIFICATIONS:

Dimension:	145 x 145 x 180 mm
Weight:	580g (main unit only)
Power Source:	100 – 240 VAC, 50/60 cycles, Output: 9 VDC (female plug) 400mA
Sound:	Predatory calls of hawk, owl species plus distressed bird calls
Flashing Strobes:	3 x Super Bright LED
Protection Coverage:	AUTO Mode: Up to 1 acre (when volume control knob turned to maximum) PIR Mode: Fan shaped area of 130°, distance up to 12 meters (163 square meters)
Material:	Housing: ABS plastic



Made in Taiwan